


To use the driving range and data:


1. Touch “Practice” window



4. Touch the club to hit




2. Touch “Distance Range”




5. Place ball in the area on the screen





3. Touch “Start Session”



6. To change your club click the club number



7. To end session and return to menu
touch the 3 bars in the lower right
hand corner, then “End Session”
DO NOT SAVE DATA when prompted




To play one of our downloaded courses:


1. Swipe left and touch “Play”




2. Touch “Home Tee Hero” window




3. Touch “Downloaded”



4. You can add more players here then touch “Next”




5. Touch the tees to play and touch “Next”




6. You can select the holes to play then touch “Start Playing”

**Putting is automated on our simulator



7. To end your round touch the 3 bars, then touch “End Round” to return to main menu



Tips and Tricks